


Paolo Balsari
DiSAFA - University of Torino
paolo.balsari@unito.it




SPRAY DRIFT DEFINITION



SPRAY DRIFT: "Quantity of plant protection product that is carried out of the sprayed (treated) area by the action of air currents during the application process" (ISO 22866)

THE «WEIGHT» OF DRIFT

In terms of potential water contamination




Spray drift is quantitatively among the <u>less</u> <u>important</u> entry routes to water, but the <u>most</u> visible



Perceived importance of diffuse sources

(Stakeholder survey 2016)

rank 1 = most important Rank 3 least important



Big differences in drift perception between NORTH / SOUTH

(Drift is visible: more orchard, vine crops, tourist interactions in South)

HOW TO REDUCE SPRAY DRIFT LOSSES





DIRECT

Reducing drift at source



Use of Spray Drift Reduction Technology (SDRT)



- Regulatory activities

No spray zones **Buffer zones**

Reducing exposure to drift

INDIRECT

Natural vegetative strips Windbreaks, hail nets, etc.

- Application equipment
- Adjustment of sprayers
- Application parameters
- Application scenario

- Fixed buffer zones
- Adjustable buffer zones (depending on spray application) technology)

KEY Factors influencing spraydrift

indirect influence

- Wind speed
- Wind direction
- Temperature
- Air humidity
- Proximity to water
- Proximity sensitive area
- Crop treated
- Adjacent vegetation
- Droplet size
- Application technique
- Adjustment of sprayers










Be aware of the external conditions when spraying close to sensitive areas

Proximity to sensitive areas



Plan thoroughly your application if you need to spray in the zone of awareness

Respect distance regulations Select optimal time of the day

Wind speed Wind direction

Temperature Air humidity

If possible post pone spraying when wind blows towards sensitive area and wind speed is > 3 to 5 m/s

Spray when temperature is < 25 degrees and air humidity is > 40 %



Key parameters to reduce the spray drift

Field applications

- Droplet size
- Distance to target
- Forward speed


Orchard applications

- Droplet size
- Distance to target
- Air volume
- Air speed
- Air direction

All these parameters are important for the correct adjustment of the sprayer

Spray drift key factor: Droplet Size

- Droplets below 100 micron cause the main drift risk
- Small droplets are lost by wind, thermic turbulence and may evaporate at low air humidity
- Coarse droplet spectra have shown comparable biological activity



Avoid droplets < 100 micron

Modification of droplet spectrum is an efficient mitigation measure to reduce spray drift!

ANTIDRIFT NOZZLES - Droplet size

TurboDrop



ID 90-xx



AVI 80-xx



IDK 90-xx CVI 80-xx



Advantage of Antidrift nozzles:

low fraction of fine droplets Ø < 100 μm →
Reduces spray drift up to 95 % (classification 50%, 75%, 90%)
No disadvantages of Antidrift nozzles

- Large number of trials show comparable biological activity for most PPP
- Perceived disadvantage: not visible spray cloud


Adoption of low drift nozzles higher in field applications compared to bush & tree crops


Big variations among regions / countries



BMP: Reduce distance to the target


- Reduce boom Hight






- the higher the boom the more influence of the wind to produce drift
- Boom stability for large booms important to keep boom height at 50 cm.

OTHER TYPES OF SDRT FOR FIELD SPRAYER: END BOOM NOZZLES



Traditional boom





Boom equipped with an «asymmetric jet» at the boom end



Drift reduction = 10-20%


BMP: Reduce forward speed in enviromental critical situation

In field applications spraying speed should be < 8 km / h along sensitive areas and when environmental wind is present



The longer the spray stays out of the canopy the more wind can cause spray drift

OTHER TYPES OF SDRT FOR FIELD SPRAYER: Spray boom with air support



SPRAY DRIFT KEY FACTORS IN <u>ARBOREAL</u> CROPS

- Nozzles type / pressure (droplet size)
- Nozzles open / orientation
- Air direction
- Air volume / speed

Sprayer adjustment is a key for drift reduction




AVI 80-xx

80.54

BMP: use nozzle technology to reduce small droplets USE ANTIDRIFT NOZZLES



Key aspects in orchard/vine crops Adjust air direction /speed and volume to the crop canopy characteristics



Adjustment through correct setting of deflectors Adjustment of axial fan sprayers is difficult

Several adjustments needed during the season as canopy develops



How to adjust air direction in practice


OPPS



BMP: Adjust deflectors position in order to adress the air into the canopy

BMP: Adjust spray to the crop target

Adjustment to tree height - Correct number and direction of nozzles




2 Drift trials Italy: measured drift reduction 65 to 70 %

Windspeed: 1,4 to 2,1 m/s

Source: Paolo Balsari, Paolo Marucco, Marco Grella, Simone Savoia
DiSAFA — Department of Agricultural, Forestry and Food Science, Turin; Suprofruit conf 2015 Lindau

BMP: Reduce Distance to target

- Sprayer designs are available to reduce spray drift




Measurement of drift reduction on complete sprayer and its configuration – a challenge

Pictures: Ipach DLZ-Rheinpfalz

INDIRECT SPRAY DRIFT REDUCTION MEASURES



Buffer zones



Wind breaks



Drift reduction up to 80%

Hail nets



Drift reduction up to 50%



Understand more about spray drift and drift reduction www.TOPPS-drift.org



Field crops / Orchards / Vine – 8 languages Education and awareness

CONCLUSION

Key parameters to reduce the spray drift risk

Field applications

Orchard applications

Droplet size

Droplet size

Distance to target

Distance to target

Air volume

Forward speed

Air speed

Air direction

Most important is the correct sprayer adjustment



Improve users training: a challenge



... We have means for the cloud to disappear